

If the vehicle has a single-axle and is a pickup cab, see below, you will use the DC204 on the smaller cab and the DC203 on the larger. For example, a cab equivalent to a Ford F-600 or smaller would be a DC204 system. If the cab is larger than a Ford F-600 (e.g., F-650), then use our DC203.

DC204



DC203



DC203



DC203



Above is a visual of how a DC203 looks with the smaller cab. It's a little awkward.